

How to Get System Log from K518

如何从 K518 获取系统日志


Note: Please connect the device to network before operating.

注意：操作之前，请将设备连上网络。




Hold those two buttons marked in red at the same time, you will enter the interface below.

同时按住红框中的两个按钮，您会进入如下界面。




Click “System Information” once and you will enter the interface as shown below. Click the area marked in red for five to eight times in one second continuously and quickly. And then click the area marked in green once.

点击“系统信息”一次，您会进入如下图所示的界面。一秒内连续而快速地点击红框中的区域五到八次。然后点击绿框中的区域一次。



You will enter the interface below once again.

您会再次进入如下界面。




Hold the return key of the device for several seconds, you will enter the interface as shown in Picture 6. Click “Get System Log” once.

按住设备的返回键几秒，您会进入如图 6 所示的界面。点击

“获取系统日志”一次。





Picture 6

图 6

Then you can click “Quit” to exit the interface.

接下来您可以点击“退出”以退出该页面。

These are all steps of getting system log from K518.

这就是从 K518 获取系统日志的所有步骤。