


1. Register a user

- 1 Tap "I have read it" and tap "LOGIN" on the right upper corner to enter login interface:



2

Username/Phone/Email

Password

Login

Register

Forgot Password


Disclaimer

1. Do not use the product before reading this X-431 V+ User Manual.
2. Do not operate this product during driving to reduce traffic danger due to lack of concentration. Launch shall not be liable for any traffic accident or economic loss arising from the use of this product.
3. The product achieves the data collecting and transfer via Bluetooth. To ensure smooth transfer, do not use this product in places with strong electromagnetic interference (e.g. high voltage transmission and distribution equipment).
4. Launch shall not be liable for any direct or indirect damage to the product due to unauthorized modification or

I have read it

- 2 Tap "Register"

- 4 Tap "Activate" to enter connector activation interface (Refer to "Activate Connector" on next page for details).




4

Sign Successfully

To diagnose cars, connector must be activated

Activate



3

Return

Username

Password

Confirm Password

Email Address

Register and Log In

- 3 Fill in information, and then tap "Register and Log In".

2. Activate Connector

Method 1 Tap "Activate" on previous page:

Connector Activation

Serial Number:

Verification Code:

Confirm

Note: Product serial number and verification code is shown in below envelope

Input Product Serial Number and Verification Code, which can be obtained from the confidential paper (See below figure). After inputting, tap "Confirm".



Method 2 If you did not activate the connector in process of registration, proceed as follows:

1. Tap **Function** icon.



2. Tap **Profile** icon.



4. Input S/N and verification code, and tap Activate.

Connector Activation

Serial Number:


Verification Code:

Activate

[How to retrieve verification code?](#)

Product in this type is not registered yet.

3. Tap **Connector Activation**.



3. Download Software

1

1. Tap **Function** icon.



2

2. Select **Update**.




4

4. Once download is complete, the system will decompress automatically and then install it. A logo corresponding to the software will appear.

Software Name	Version	Progress	Status
BXFIAT	V10.13	<div style="width: 50%;"><div style="background-color: yellow;"></div></div>	Downloading
HOLDEN	V42.01	<div style="width: 50%;"><div style="background-color: yellow;"></div></div>	Downloading
ISUZU (Japan)	V15.20	<div style="width: 0%;"><div style="background-color: gray;"></div></div>	Waiting to Download...
SKODA	V26.80	<div style="width: 0%;"><div style="background-color: gray;"></div></div>	Waiting to Download...
ZHONGTAI	V17.11	<div style="width: 0%;"><div style="background-color: gray;"></div></div>	Waiting to Download...
ZHONGXING	V21.02	<div style="width: 0%;"><div style="background-color: gray;"></div></div>	Waiting to Download...

3

3. Select the desired vehicle, and tap  to download.

Note: All software are selected by default. To deselect a certain vehicle software, just uncheck the box.

Car Model	Version	
BXFIAT	V10.13	<input checked="" type="checkbox"/>
HOLDEN	V42.01	<input checked="" type="checkbox"/>
ISUZU (Japan)	V15.20	<input checked="" type="checkbox"/>
SKODA	V26.80	<input checked="" type="checkbox"/>
ZHONGTAI	V17.11	<input checked="" type="checkbox"/>
ZHONGXING	V21.02	<input checked="" type="checkbox"/>
ACURA		<input checked="" type="checkbox"/>
AUDI		<input checked="" type="checkbox"/>
BENZ		<input checked="" type="checkbox"/>