

CAS 4+ Copy key with key


CG-DI

CAS 4+ anti-theft BMW car keys increase, need to read anti-theft data separately to match the key


Operating CG-Pro Read CAS 4+ anti-theft data




CAS 4+ anti-theft computer module style




CAS 4+ anti-theft computer module




Software physical wiring diagram



Physical connection




Connect the CG-Pro




Decrypt successfully and save the data


Operating CG – DI Match the new key




Click on the "CAS4 key match"




Load CAS 4+ data read by CG-Pro




Select data and click open



Display relevant information




Select the key position that needs to be configured, click to generate the dealer key, and click on the engine data to determine the next step






Read the working key






Put the new key in CG-DI



New key programming success



After learning, it can be used normally