


Identify key types and information CG-MB

version 51



Insert the key into CG-MB




Read and display related key information

version BE




Insert the key into CG-MB




Read and display related key information

Version FBS4



Insert the key into CG-MB



Read and display related key information